

# UTAH DEPARTMENT OF TRANSPORTATION

## Ports of Entry COMBINED TRANSPORTATION AND TAX COMMISSION PERMIT

4501 South 2700 West  
Salt Lake City, UT 84119-5998  
During regular business hours: (801)965-4892 or toll free: (866)215-5399  
<http://www.udot.utah.gov/go/motorcarriers>

### Travel Restrictions

**\* Travel 24 hours a day if 8'6"-10' wide and not exceeding , or 105' length, or 14' height or those with overhangs when meeting the following requirements:**

- \* **10' wide:** Must have marker lights indicating extreme width, amber lights at the front and center of the load, and red lights at the rear.
- \* **Overhang:** Overhang in excess of 4' to the rear requires lights and flags.
  - Overhang in excess of 3' front and 6' rear overhangs require a permit.
  - Refer to the *Certified Pilot/Escort Requirements, Police Escort Requirements and Darkness Hours when exceeding 10' overhangs online at <http://www.udot.utah.gov/go/mcdmain> (limited information in box below).*
  - Overhang in excess of 20' on the front or rear must have a flashing amber light on the end of the load and one certified pilot/escort.
- \* **14' height:** There are no requirements on a load this size.
- \* **105' length:** Loads in excess of 92' must have proper lighting and an oversize load sign. Night travelers must have amber lights at the beginning of load and then again every 25', with red lights to the rear of the load. (See the Utah Trucking Guide for legal vehicles dimensions.)

### Restrictions for loads exceeding 10' wide, or 105' length, or 14' height:

- \* **Holidays:** Travel prohibited on the six major observed holidays (New Year's Day, Memorial Day, Independence Day, Labor Day, Thanksgiving Day and Christmas Day). Refer to <http://www.udot.utah.gov/go/mcdholidaytravel> for restrictions.
- \* **Curfew Hours:** Travel prohibited during curfew hours (Mon- Fri from 6:00 am to 9:00 am and 3:30 pm to 6:00 pm) for the following:
  - \* All highways south of Perry Interchange (I-15, Exit 357).
  - \* All highways in Weber, Davis, and Salt Lake counties.
  - \* All highways north of Ironton Interchange (SR 75, I-15, Exit 261).
  - \* All highways in Utah County north of SR 68, MP 16.
- \* **All loads:** Red flags and oversize load signs are required. (Exception: oversize sign not required on loads that are oversize due to overhang only unless overall length exceeds 105').

### Pilot/Escort Requirements

Daylight Hours	Freeway & Interstates	Secondary (non-Interstate)	Darkness Hours	Freeway & Interstates	Secondary (non-Interstate)
1 Pilot/Escort	<u>Exceeding</u> Width: 14' Length: 120' Overhang: 20'	<u>Exceeding</u> Width: 12' Length: 105' Overhang: 20'	1 Pilot/Escort	<u>Up to 14' wide, exceeding</u> Width: 10' Length: 105' Overhang: 10'	na
2 Pilot/Escort	<u>Exceeding</u> Width: 16' Height: 16'	<u>Exceeding</u> Width: 14' Height: 16' Length: 120'	2 Pilot/Escort	na	<u>Up to 12' wide, exceeding</u> Width: 10' Length: 105' Overhang: 10'

### Police Escort Requirements

All Hours	Freeway & Interstates	Secondary (non-Interstate)	Police Escort Notes:
* At least 1	<u>Exceeding</u> Length: 175'	<u>Exceeding</u> Length: 175'	<b>Note: *Indicates that the number of police escorts needed is determined by the area, time, and difficulty of travel as well as local and state rules and regulations. Police escorts can be obtained by contacting (801)965-4518 or the police station in your area of travel.</b>
* At least 2	<u>Exceeding</u> Width: 20' Height: 17'6" Length: 200'	<u>Exceeding</u> Width: 17' Height: 17'6" Length: 200'	

### UTAH PORTS OF ENTRY

**On-line Permitting <https://www.udot.utah.gov/public/mcs/>**

Central Permitting Salt Lake City	(801)965-4892	*Kanab	SR US 89, No. of town, MP 67	(435)644-5871
St. George I-15, Utah-AZ Line, MP 1	(435)673-9651	*Monticello	SR US 491 E. of town, MP 2	(435)587-2662
Wendover I-80, Utah-NV Line, MP 3	(435)665 2274	*Peerless	SR US 6, No. of Helper, MP 231	(435)472-3401
Echo I-80, Utah- MP 181	(435)336-5286	*Daniels	SR US 40, So. of Heber, MP 20	(435)654-1091
*Perry I-15, So.of Brigham City, MP 358	(435)734-9414			

*Note: \* Indicates locations where permits are required prior to entering the state. Permits are also required prior to moving a load during intrastate travel. Please contact a Port of Entry before entering the state for additional information.*